## THE KANGAROO PRO JUNIOR

2.

HOW TO INSTALL YOUR MONITOR - attaching your monitor to the Ergo Desktop mount, 5/32 allen wrench and M4 screws provided



1.



Place VESA Mount on the Back of Your Monitor and Line Up the Holes. NOTE the Location of the Slots in the VESA Mount. Attach Mount With 4 Screws. Visually Line up the Mount With Your Monitor and Tighten.



Remove VESA mount and separate washers as shown. VESA mount fits between washers




Remove the Base From Your Monitor and Lay it Face Down on a Soft surface



(This May Require 2 People) Pick up Monitor and Guide The Slots of the VESA Mount Between the Washers



are now ready to attach your cords and go!!!



## How to Use the Pro Junior

To raise the Pro Junior, loosen the main brake(D) and lift the main work surface on the sides(E & E). After reaching the desired height, tighten the work surface brake. Loosen the monitor brake(B) and raise the monitor. After reaching the desired height tighten the monitor brake. Place the stabilization leg included with your unit, between the work surface and steel base plate.

To lower the Junior, remove the stabilization leg, loosen the main brake(D) and lean into the unit using your upper body weight pushing down with both hands on the horizontal bar at the rear of the main horizontal work surface (C & C). After the Work Surface is lowered, tighten the work surface brake(D) and loosen the monitor brake(B). Lower the monitor to the desired height then tighten the monitor brake.

- A. Mount Brake controls tilt
- **B.** Monitor Brake
- C. Work Surface Rail
- D. Main Brake
- E. Main Work Surface

## THE STABILIZATION LEG





Stabilization leg showr vithout the Extension Selection Your adjustable height desk unit comes with an adjustable leg that can be used to give you maximum stability when you are using "The Kangaroo" in the standing position.

Raise The Kangaroo work surface to your desired standing height and tighten the work surface brake.

Place the adjustable leg under the work surface and loosen the adjustable leg brake. Only loosen the brake by a turn or two, to much and the brake will disengage from the slot.

Extend the adjustable leg until it engages the bottom of the work surface and then tighten the adjustable leg brake.

The leg is shipped with the extension section installed to give you additional height adjustment. If this is too tall for your application, simply unscrew the extension section.



A Extension Selection

B screws into here

## ALWAYS REMOVE LEG BRACE BEFORE LOWERING THE WORK SURFACE.

